PRIMEX

Media Panel Installation Instructions

SOHOpro™ PR1500

Allfield Media Panel

The Primex PR1500 Allfield Media Panel is an all-in-one new build and retrofit WiFi transparent enclosure. It mounts in-wall, on-wall or free standing for single or multi-family applications. The unique, patented Smart Lid is self-aligning and closing with an adjustable depth and clean aesthetics. The PR1500 provides ample room for multi-play applications from broadband to smart home installations.

WARNING

- **DO NOT** stretch enclosure walls or lid won't seat properly.
- DO NOT over tighten mounting screws.
- **DO NOT** use mounting screws larger than #8.
- **RECOMMENDED** mounting height, 36" 48" from the floor.
- LEAVE paintshield in during installation to protect enclosure during drywall installation and painting.
- * On-wall maximum load rating: 10kg (22lbs)

GREENFIELD Installation

STEP 1

Install horizontal joist and electrical box

To ensure a comfortable working height it is recommended that the top of the electrical box be installed 36" - 48" from the ground. Ensure that the support joist is level.

Note: Install if required by your local electrical code.



STEP 2

Remove bottom knock outs

Prior to installation, remove required knockout covers. Then, remove the knockout(s) for the electrical box using a Primex (P/N: 125-1683) flush cutter tool to trim support ribs. Trim excess plastic with knife.

Supports drop-in and under-mount gangbox installations.






STEP 3

Install base

Install single #8 flat head screw in corner flange, level, then secure with additional screws.



STEP 4

Install Electrical Kit

Place gangbox into cut out knockout, connect power and secure receptacle to gangbox using screws.

Note: Secure gangbox to horizontal joist if required by your local electrical code.



FOR MORE INFORMATION CONTACT:

1.604.881.7875 **1**.604.881.7835

www.primex.com



Media Panel Installation Instructions


SOHOpro™ PR1500

Allfield Media Panel

STEP 5

Remove top knock outs and connect distribution conduit

Remove the conduit knockouts using a flush cutter tool and blunt force tool. Connect conduit for outgoing and incoming services and secure with Primex conduit reducers (3/4"-1/2" reducers P/N: 125-1022, 1" - 3/4" reducers P/N: 125-0936).




STEP 6

Measure, mark, cut and mount drywall

Measure, mark, then cut drywall where enclosure will be mounted. Fit drywall over top of the installed enclosure base and secure.








STEP 7

Paint wall and affix smart lid

Leave paintshield in during installation to protect enclosure during drywall installation, mudding and painting.



Optional Low-Profile Hinged Lid (P/N: 125-1739)

Affix hinged lid

Position frame over top of installed base. Secure one corner with provided screw. Level frame and fasten with remaining screws. Ensure lid closes correctly.





FOR MORE INFORMATION CONTACT: 1.604.881.7875 1.604.881.7835

www.primex.com



Media Panel Installation Instructions

SOHOpro™ PR1500

Allfield Media Panel

BROWNFIELD Wall-mount Installation

STEP 1

Wall mount install

Using a stud finder, mark position at a recommended height of 36" - 48"

Pre-drill holes in the center slots of the enclosure prior to mounting.






STEP 2

Remove knockout and insert optional keystones.

Trim support ribs on knockout using flush cutter tool. (P/N: 125-1683) Snap in keystone adapter (P/N: 125-1152 sold separately) and install optional keystones (available from Primex).

Remove knockouts for power as needed.



STEP 3

Affix PR1500 to stud

Affix PR1500 on a single stud using two No. 8 wood screws in the pre-drilled holes. Be sure to level before securing the bottom screw.







STEP 4

Affix Smart Lid

Place smart lid into place. Optional key lock kit (P/N: 125-1570) and hex lock kit (P/N: 125-1641) available.





FOR MORE INFORMATION CONTACT:

1.604.881.7875 1.604.881.7835

www.primex.com



PRIMEX

Media Panel Installation Instructions

SOHOpro™ PR1500

Allfield Media Panel

BROWNFIELD Freestanding Installation

STEP 1

Prepare enclosure

Remove lid. Trim support ribs on knockouts using flush cutters.







STEP 2

Install keystone adapter

Snap in optional keystone adapter (P/N: 125-1152 sold separately) and jacks.






STEP 3

Attach feet

Install accessory feet (P/N: 125-1571 sold separately) using the screws provided.





STEP 4

Finish Installation

Connect services and mount additional components using Primex's mounting systems. Optional key locks available (P/N: 125-1570).





ACCESSORIES

Product	Description	SC	Product	Description	SC	Product	Description	SC
*	7" RMP w/RMB2 (x2), pushpins (x10) 7" RMP w/RMB (x2), pushpins (x10) 7" RMP w/RMK (x2), pushpins (x10) 10" RMP w/RMB2 (x4), pushpins (x10)	125-1655 125-1656 125-1657 125-1658	8	Fiber Transition Case (FTC2) FTC2 - Standard FTC2 - w/SC/APC fiber adapter FTC2 - w/angled shutter SC/APC adapter	125-1778 125-1828 125-1827		Cat5e, 110 IDC, 90° HD Cat5e, 110 IDC, 180° HD Cat6, 110 IDC, 90° HD Cat6, 110 IDC, 180° HD Cat6A, 180°, Unshielded	125-0949-WT 125-0948-WT 125-0947-WT 125-0946-WT 125-1628-WT
	10" RMP w/RMB (x4), pushpins (x10) 10" RMP w/RMB2 (x2)/RMK (x2), pushpins (x10)	125-1659 125-1660		Fiber Transition Outlet (FTO) FTO-w/1 SC/APC Adapter FTO-w/Integrated Splice Tray	125-0889 125-0879	See a see	Cat6A, 180°, Shielded 3-Line RJ12 Voice Jack	125-1629-WT 125-0959-WT
	Universal Mounting Plate (UMP)	125-0770		SC/APC Fiber Keystone w/Shutter	125-0908		Blank keystone	125-0960-WT
	10" UMP w/5' tape, pushpins (x10)	125-1623	J. J.	Keystone Adapter	125-1152		Cat5e coupler, HD Cat6 coupler, HD	125-1266-WT 125-1267-WT
	Shelf Mounting System (Single-1/pk) Shelf Mounting System (Divider-2/pk) Shelf Mounting System (bulk-18/pk)	125-1541 125-1542 125-1522		3/4"-1/2" Reducer 1"-3/4" Reducer	125-1022 125-0936		RG12 coupler, HD PR1500 Freestanding Feet (2)	125-1268-WT 125-1571
0	33' Roll Of Mounting Tape 10' Roll Of Mounting Tape	125-0779 125-1274		2-Way Coax Splitter (horizontal) 4-Way Coax Splitter (vert/horiz) 6-Way Coax Splitter (vert/horiz)	125-1661 125-1574 125-1575		PR1500 Key Lock Kit (2)	125-1570
4	Mounting Plate Pushpins (100/bag) Mounting Plate Pushpins (10/bag)	125-0829 125-1535		8-Way Coax Splitter (vert/horiz)	125-1576	· ·	PR1500 Hex Lock Kit (2)	125-1641
	8-Port Cat5e Data Module 8-Port Cat6 Data Module	125-0986 125-1035		Electrical Installation Kit 360° Electrical Rotating Outlet	125-1355 125-1547		FR 1300 FIEX LUCK NIL (2)	123-1041
	8-Port Cate Data Module 8-Port Voice RJ31x Module 6-Port Cat6a Data Module	125-1035 125-0987 125-0975		Cable Management Hurricane Clip (12/pk)	125-0239	T	PR1500N Key Lock Kit (1)	125-1841
	8-Port Voice Cat6 w/RJ45 Module 1x8 Port 4 Line w/RJ45 Voice Module	125-0977 125-0976		F-Connector Keystone	125-0961		PR1500N Hex Lock Kit (1)	125-1774

FOR MORE INFORMATION CONTACT:

1.604.881.7875 **1**.604.881.7835

www.primex.com

