

Installation Instruction


"THE BOSS" NTL600E LOUD RINGER

Issue C: January 2007


Introduction

The NTL60E is a loud Universal Electronic Ringer designed for use in noisy locations or for wide area coverage. The NTL600E was designed for use with the Public Telephone Network and can also be used behind PBX and Key Systems with dry relay contact or analog station ports.

- Works on all phone systems, dry contact or 90 volt ringing
- Choice of 8 selectable sound patterns: Horn, Bell, Warble H, Warble M, Warble L, Chime, Timeclock, Siren
- Choice of 2 operating Voltages: 24VDC, 48VDC
- Indoor and Outdoor Mounting
- Terminal screws or modular line cord plug-in
- Up to 115DB @ 70ma



NTL600E Loud Ringer





WARNING: DO NOT STAND TOO CLOSE TO THE ntl600 WHEN TESTING OR OPERATING. TOO MUCH EXPOSURE AT CLOSE RANGE MAY BE HARMFUL TO YOUR HEARING. NTL600E'S SHOULD BE LOCATED AT LEAST 10 FEET AWAY FROM LISTENERS

Installation Instruction continued...

Typical Installation

The illustrations below show the connections required to install a NTL600E Loud Ringer:



Head Office

27 Armthorpe Rd. Brampton, Ontario L6T 5M4
1-800-668-3402 Tel: 905-790-1234 Fax: 905-790-1122

Markham Office

450 Alden Road (Unit #1), Markham, Ontario L3R 5H4
1-866-574-0123 Tel: 905-752-1234 Fax: 905-752-600

Quebec Regional Office

2808 Rue J.A. Bombardier, Laval, QC H7P 6E4
1-800-361-7793 Téléphone: 450-682-1511 Télécopie: 450-682-1577

Calgary Office

1235- 64th Ave South East, Bay 10, Calgary, Alberta Canada T2H 2J7
1-866-680-0123 Tel: 403-286-1234 Fax: 403-247-0123